

SWITCH SEQ NO	COLOURS & MODES SELECTION
1	WHITE
2	SLOW CHANGING COLOURS - 20 SEC RAMPING
3	FAST CHANGING COLOURS - 5 SEC RAMPING
4	BLUE
5	MAGENTA
6	RED
7	YELLOW-GREEN (GOLD)
8	GREEN
9	AQUA

## Notes:

- 1. Colour selection is achieved by switching the light switch ON/OFF
- 2. The last selected colour will be the default colour after switching lights OFF for at least 15 seconds.

